Service Manual

Pioneer

SATELLITE SUBWOOFER



ORDER NO.
RRV2484

SPEAKER SYSTEM
S-L11-Q-LRW

XJI/EW

● **This product is component of system.**

Component		System	Service Manual	Remarks
COMPACT MINI COMPONENT		————	————	
	SEREO CD TUNER	XC-L11	RRV2470	
	STEREO POWER AMPLIFIER	M-L11	RRV2479	
	SPEAKER SYSTEM	S-L11-Q-LRW	RRV2484	This service manual

65S

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

This product contains lead in solder and certain electrical parts contain chemicals which are known to the state of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 – Proposition 65

FOR PRECAUTION OF REASSEMBLY AND DISASSEMBLY

(Satellite)

- The grille is attached to the cabinet by 4 external screws. To detatch it ,unfasten those screws.
- The speaker element is attatched to the baffle by 4 internal screws. To detach it, first remove the cabinet . Then remove the speaker element by unfastening those screws. When attatching it, face its terminal upward.

(Subwoofer)

- The cosmetic baffle is attached to the baffle by press-fitting. To detatch it , pry it open by inserting a flat blade screwdriver into lower side.
  To attach the cosmetic baffle, replace it on the backboard correctly by press-fitting.
- The input terminal is attached to the backboard by press-fitting. To detatch it , pry it open by inserting a flat blade screwdriver into lower side.
  To attach the input terminal, replace it on the backboard correctly by press-fitting. (The red terminal is right side.)
- The woofer is attatched to the backboard by 4 external screws. To detach it, unfasten those screws. When attatching it, face its terminal downward.

PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan
PIONEER ELECTRONICS SERVICE, INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.
PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium
PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936
© PIONEER CORPORATION 2001

T – ZZV JUNE 2001 Printed in Belgium

PARTS LIST

NOTES: ● *Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.*
● *The ⚠ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.*

PARTS LIST

Mark	No.	Description	Part No.
NSP		Satellite Speaker	SMW1661
NSP		Subwoofer	SMW1662

For Packing

NSP		Accessary Set	SEA1561
	├	Speaker Wire (for Subwoofer)	SDF1091
	├	Speaker Wire (for Satellite)	SDS1065
	├	Non Skid Pad	SEC1537
	├	Stand	SET1041
NSP	└	Polyethylene Bag	SHL1223
		Top Protector	SHA2310
		Middle Protector	SHA2311
		Bottom Protector	SHA2312
		Packing Case	SHG2338
NSP		Polyethylene Bag (for Subwoofer)	SHL1212
		Polyethylene Bag S2 (for Satellite)	SHL1291

SCHEMATIC DIAGRAM

Satellite



Subwoofer



● Satellite Speaker

PARTS LIST

Mark	No.	Description	Part No.
		Speaker	D87DU61-53F
		Screw (for Speaker)	BPZ40P060FZK
		Screw (for Cabinet)	BPZ40P120FZK
		Screw (for Sidewood)	BYC35P160FNI
		Fin-Lok M5 (for Stand attaching)	SBN1049
		Speaker Cord	SDD1303
		Packing (for Cabinet)	SEC1532
NSP		Packing (for Cabinet)	SNK2541
		Damper (for Cabinet, Grille)	SEP1237
		Input Terminal	KKX1015
		Grille	SMG1723
NSP	├	Badge23	SAM1487
NSP	├	Grille Cloth	SAS1497
NSP	└	Grille Frame	SMH1030
NSP		Sidewood R	SMS1440
NSP		Sidewood L	SMS1441
NSP		Acoustic Absorbent (for upper back side)	SMV2090
NSP		Acoustic Absorbent (for lower back side)	SMV2091
NSP		Cabinet	SNK2536
NSP		Stamped Model Label	SME3150
NSP	└	Label Back	SAN2942

● Sub Woofer

PARTS LIST

Mark	No.	Description	Part No.
		Speaker	A14ER75-52C
		Screw (for Speaker)	BYC40P160FZB
		Speaker Cord	SDD1304
NSP		Packing (for Cosmetic Baffle)	SEC1567
NSP		Paper Tube 50	SMR1340
		Input Terminal	KKX1014
		Non Skid Pads	SEC1534
NSP		Acoustic Absorbent (for bottom side)	SMV1955
NSP		Acoustic Absorbent (for upper front side)	SMV2003
NSP		Cabinet	SMM1941
NSP		Cosmetic Baffle	SNK2532
NSP		Stamped Model Label	SME3152
NSP	└	Label Back	SAN2944

● Satellite Speaker



No.	Part name	Num	Remarks	No.	Part name	Num	Remarks
1	Cabinet	1		11	Screw	4	BPZ40P060FZK
2	Grille	1		12	Screw	4	BPZ40P120FZK
3	Sidewood R	1		13	Screw	6	BYC35P160FNI
4	Sidewood L	1		14	Label Back	1	
5	Speaker	1		15	Damper	2	SEP1237
6	Speaker Cord	1		16	Damper	1	SEP1237
7	Input Terminal	1		17	Packing	1	SEC1532
8	Acoustic Absorbent	1	SMV2090	18	Acoustic Absorbent	1	SMV2091
9	Fin-Lok M5	2					
10	Packing	2	SNK2541				

● Sub Woofer



No.	Part name	Num	Remarks	No.	Part name	Num	Remarks
1	Cabinet	1		8	Paper Tube 50	1	
2	Speaker	1		9	Label Back	1	
3	Cosmetic Baffle	1		10	Non Skid Pad	4	
4	Acoustic Absorbent	1	SMV1955	11	Packing	1	SEC1567
5	Acoustic Absorbent	1	SMV2003	12	Screw	4	BYC40P160FZB
6	Input Terminal	1		13	Packing	2	SEC1568
7	Speaker Cord	1					